



Item#: A20287

Description :

Keep your clubs and shoes clean anywhere on the course with the IZZO Aqua Brush, a convenient multipurpose cleaning tool designed for on-the-go performance. The refillable handle can be filled with water or a water-and-soap mixture to help remove dirt, mud, sand, and debris for a thorough clean before every shot. Durable nylon bristles provide a deep yet gentle clean for clubfaces, while a secondary brass brush is ideal for tougher cleaning on shoes and stubborn areas. A heavy-duty retractable cord allows easy attachment to your golf bag for quick access throughout your round.

Order Notes: Stock product is not returnable.

Colors



BLACK


Production Details

| | |
|-----------------|--------------------------|
| Production Time | 2-3 Business Days |
| FOB | Macedon, New York, 14502 |

Imprint Details

| | |
|------------------|-------|
| Pricing Includes | 0 / 0 |
|------------------|-------|

Images



How to Use View (A20287)